



***CURVE - AUFBAUANLEITUNG***

***CURVE - SETUP INSTRUCTIONS***

# AUFBAUANLEITUNG

## SET UP INSTRUCTIONS



# AUFBAUANLEITUNG

## SET UP INSTRUCTIONS



### INSTRUCTIONS

Required tools: 3-5 ladders, 4mm Allen key

1-2 Assemble the upper and lower horizontal elements according to the numbering and fasten them (1 Nm) 3-4 unfold the lateral vertical elements and plug them with the lower horizontal corner elements according to the labeling and tighten the thread bolts with the allen key 5-7 unfold the center support and bolt them to the lower horizontal frame section according to the labeling with the enclosed wing screws 8-9 attach the upper frame section to the top end of the vertical frame sections with at least 3 people

10-12 unfold the projection surface with, according to the screen size appropriate number of people and hook it onto the rail of the upper horizontal frame section and slide it with several people gently till the opposite corner. 13 Now attach the snap fasteners on the lateral sides.

To attach the hooks to the lower frame bar easily, it is recommended to set up the projection screen on T-Legs, or at least to raise the screen a bit with squared timbers.



[www.AVstumpfl.com](http://www.AVstumpfl.com)

AV Stumpfl GmbH | A 4702 Wallern | Mitterweg 46  
AVstumpfl@AVstumpfl.com | [www.AVstumpfl.com](http://www.AVstumpfl.com)  
tel.: +43 (0) 7249 / 42811 | fax: +43 (0) 7249 / 42811-4

Änderungen dienen dem technischen Fortschritt und bleiben vorbehalten.

We reserve the right to make modifications in the interest of technical progress.